Spring Home Maintenance Schedule

Homestead Handyman Service (905-263-8339)

- 1. After consulting your hot water tank owner's manual, carefully test the temperature and pressure relief valve to ensure it is not stuck. (Caution: This test may release hot water that can cause burns.)
- Check and clean or replace furnace air filters each month during the heating season.
 Ventilation system, for example heat recovery ventilator, filters should be checked every two months.
- 3. Have fireplace or woodstove and chimney cleaned and serviced as needed.
- 4. Shut down and clean furnace humidifier, and close the furnace humidifier damper on units with central air conditioning.
- 5. Check air conditioning system and have serviced every two or three years.
- 6. Clean or replace air conditioning filter (if applicable).
- 7. Check dehumidifier and clean if necessary.
- 8. Turn OFF gas furnace and fireplace pilot lights where possible.
- 9. Have well water tested for quality. It is recommended that you test for bacteria every six months.
- 10. Check smoke, carbon monoxide and security alarms and replace batteries.
- 11. Clean windows, screens and hardware, and replace storm windows with screens. Check screens first and repair or replace if needed.
- 12. Open valve to outside hose connection after all danger of frost has passed.
- 13. Examine the foundation walls for cracks, leaks or signs of moisture, and repair as required. Repair and paint fences as necessary.
- 14. Ensure sump pump is operating properly before the spring thaw sets in. Ensure discharge pipe is connected and allows water to drain away from the foundation.
- 15. Re-level any exterior steps or decks which moved due to frost or settling.
- 16. Check eaves troughs and downspouts for loose joints and secure attachment to your home, clear any obstructions, and ensure water flows away from your foundation.
- 17. Clear all drainage ditches and culverts of debris.
- 18. Undertake spring landscape maintenance and, if necessary, fertilize young trees.